


Weather Wizard III® INSTALLATION DIAGRAM

Weather Wizard III® Installation

This diagram shows a typical Weather Wizard III installation, including a cabled Anemometer, Rain Collector, and Temperature Sensor.



North side of building in Northern Hemisphere
South side of building in Southern Hemisphere